


How to Read Your Dial-Type Meter

Look at the first meter on the left. If the hand on the meter is between numbers (it typically is), write down the lower of the two numbers. If the meter hand is between 2 and 3, write down the 2.


Inspect the second meter number and perform the same task. Repeat this reading with all four meters.

Write out the full reading. This is the natural gas reading for the month.



Please refer to the example below for additional instruction/example:

A typical gas meter has four dials. The first and third dials spin counter clockwise, while the second and fourth dials spin clockwise. When reading the meter, if the arm is between two numbers ALWAYS use the lower number.



* If you are having trouble telling if the pointer has passed a number, look at the dial to the right of the dial in question. If the dial to the right has passed the 0, use the higher number. If the dial to the right has not passed the 0, use the smaller number.